

-KENNETH COLE NEW YORK

---

Thank you for your purchase of  
a Kenneth Cole New York watch.

Register your watch today at:  
[www.genevawatchgroup.com](http://www.genevawatchgroup.com)

---

**Kenneth Cole New York is manufactured using the highest quality materials and craftsmanship. The incorporation of both traditional and forward thinking design philosophies result in a unique and modern product.**

## LIMITED LIFETIME WARRANTY

Thank you for choosing a Kenneth Cole New York precision timepiece. This Kenneth Cole New York watch is warranted to you, the owner, for your lifetime against all defects in material or workmanship. Limited lifetime warranty will be honored only by Service Center in the United States, Canada, Caribbean as well as Authorized Duty Free and Military Dealers. Service centers located in other parts of the world will only provide warranty service for the first 2 years. However, the warranty does not apply to normal wear and tear or abuse and excludes battery, case, crystal, strap, malfunction and deterioration resulting from accident, negligence and tampering. Kenneth Cole New York watches are water-resistant. Special gasket and crown protectors have been used in the creation of these time pieces to ensure their resistance to water. In the event of a defect or malfunction, it will be repaired or replaced at our option. PLEASE DO NOT SEND CASH. No additional charge will be made unless additional servicing is necessary for reasons beyond our control such as accident, misuse, neglect or replacement of parts not warranted such as battery, case, crystal and strap. In this event, please see Watch Repair section in the back of this booklet.

## BATTERY LIFE

The battery in your Kenneth Cole New York Watch should last approximately 1 year. Please replace the battery as soon as possible to prevent any issues with the watch performance. For battery replacement, we recommend that you contact an AUTHORIZED KENNETH COLE NEW YORK DEALER. The battery type is found on the caseback.

Please Note: If you have purchased a Touch Screen Watch and you experience an unstable or delayed response while using the EL back light or when pressing the touch sensors, then this indicates the battery will need to be replaced soon. Please contact your Authorized Dealer.

## CERAMIC CARE INSTRUCTION




Ceramic is a high quality material revered for its inherent characteristics of high shine, feel, and scratch resistance featured in select styles. Over time, the shine may dull due to handling. To restore ceramic to its original luster, clean with warm soapy water and dry with a soft cloth. Buff the ceramic to its original shine with a dry soft cloth. Handle with care as ceramic may chip or break when dropped.

## WATER RESISTANCE

- Before using watch in or near water, be sure that crown is pushed in completely.
- If watch is underwater or wet, do not use pushers, rotating bezels or crowns.
- If watch becomes wet, wipe it dry as soon as possible.
- If watch comes in contact with salt water, rinse case and bracelet immediately and thoroughly under tap water and wipe dry with a soft cloth.
- Do not take your watch into a Hot Tub or Sauna. Extreme heat and pressure may cause your watch to lose its water resistance.
- Water resistance is not permanent. In the course of time, as your case becomes worn, the water resistance of the watch may decrease.

WATER RESISTANCE	SUITABLE ATMOSPHERE
3 ATM/ 30 METERS/ 100 FEET/ 30 METERS H2O	Suitable for washing hands and light splashing
5 ATM/ 50 METERS/ 165 FEET/ 50 METERS H2O	Suitable for light swimming, e.g. bathing in a pool or low tide waters, but not suitable for diving
10 ATM/ 100 METERS/ 330 FEET/ 100 METERS H2O	Suitable for most water sports, e.g. swimming, surfing and snorkeling, but not suitable for deep water diving

## TWO-HAND / THREE-HAND MODELS




1. Second Hand

(5Y20, IL45)

### TO SET THE TIME:

1. Pull crown out to first click position B.
2. Turn crown to set time.
3. Push crown back to position A.

## TWO OR THREE-HAND DATE MODELS



### 1. Date Window

### TO SET THE TIME:

1. Pull crown out to second click position C.
2. Turn crown to set time.
3. Push crown back to position A.




**TO SET THE DATE:**

1. Pull crown out to first click position B.
2. Turn crown counter-clockwise to set date.
3. Push crown back to position A.

**NOTE:** Do not set the date between 9:00 P.M. and 1:00 A.M. Otherwise, the date may not change properly on the following day. If it is necessary to set the date during that time period, first change the time to any time outside it, then set the date and then reset to the correct time.

## THREE-HAND MODELS WITH DAY/DATE

1. Day Window
2. Date Window



(GM00)

### TO SET THE TIME:

1. Pull crown out to second click position C.
2. Turn crown clockwise to set time.
3. Push crown back to position A .

### TO SET THE DATE:

1. Pull crown out to first click position B.
2. Turn crown counter-clockwise to set date.
3. Push crown back to position A .


### TO SET THE DAY (OF THE WEEK):

1. Pull crown out to first click position B.
2. Turn crown clockwise to set day.
3. Push crown back to position A .


NOTE: Please do not set the date and day between 9:00 P.M. and 1:00 A.M. Otherwise the date and day may not change correctly for the following day.

## TWO-EYE MULTI-FUNCTION MODELS


1. Second Hand
2. Day Hand
3. Date Hand



1. Second Hand
2. Date Hand
3. 24 Hour Hand



1. Second Hand
2. Date Hand
3. 24 Hour Hand



### TO SET THE DAY (OF THE WEEK):

1. Pull crown out to second click position C.
2. Turn crown clockwise to set day.
3. Push crown back to position A.

**NOTE:** The Day Hand will move together with the Hour Hand and Minute Hand. Keep turning the crown until the desired day has been reached.

### **TO SET THE TIME:**

1. Pull crown out to second click position C.
2. Turn crown to set time.
3. Push crown back to position A.

**NOTE:** The 24 Hour Hand will also be set during time setting.


### **TO SET THE DATE:**

1. Pull crown out to first click position B.
2. Turn crown counter-clockwise to set date.
3. Push crown back to position A.

**NOTE:** Do not set the date between 9:00 P.M. and 1:00 A.M. Otherwise, the date may not change properly on the following day. If it is necessary to set the date during that time period, first change the time to any time outside it, then set the date and then reset to the correct time.

## TWO-EYE MULTI-FUNCTION MODELS WITH DATE / MONTH

1. Hour Hand
2. Minute Hand
3. Second Hand
4. 24 Hour Hand /  
Second Time Zone Hand
5. Date Window
6. Month Hand



- S1. Month Set Button  
S2. 24 Hour Hand / Second Time Zone Hand Set Button

### TO SET THE TIME:

1. Pull crown out to second click position C.
2. Turn crown clockwise to set time.
3. Push crown back to position A.

NOTE: The 24 Hour Hand / Second Time Zone Hand and Date Hand will also be set during time setting.

### TO SET THE 24 HOUR HAND / SECOND TIME ZONE HAND (QUICK CHANGE FUNCTION):

1. Set crown at position A.
2. Press S2 button to set the 24 Hour Hand / Second Time Zone Hand. Each press will advance the hand by 1 unit.

**NOTE:** When using S2 button to set the 24 Hour Hand / Second Time Zone Hand, the Minute Hand must be set to between 55th minute and 05th minute at any hour.

### **TO SET THE DATE (QUICK CHANGE FUNCTION):**

1. Pull crown out to first click position B.
2. Turn crown clockwise to set date.
3. Push crown back to position A.

**NOTE:** Do not use quick change function to set date between 9:00 P.M. and 00:30 A.M. Otherwise, the date may not change properly. If it is necessary to set the date during that time period, first change the time to any time outside it, then set the date and then reset to the correct time.


### **TO SET THE MONTH:**

1. Set crown at position A.
2. Press S1 button to set the Month Hand. Each press will advance the hand by 1 unit.


**NOTE:** Do not set month on the 31st of a month.

**THREE-EYE MULTI-FUNCTION MODELS****WITH LARGE SECOND**



1. Second Hand
2. Day Hand
3. 24 Hour Hand
4. Date Hand

**WITH SMALL SECOND**

1. Hour Hand
2. Minute Hand
3. Small Second Hand
4. Date Hand
5. Day Hand



1. Hour Hand
2. Minute Hand
3. Second Hand
4. Date Hand
5. Day Hand
6. 24 Hour Hand



**TO SET THE DAY (OF THE WEEK):**

1. Pull crown out to second click position C.
2. Turn crown clockwise to set day.
3. Push crown back to position A.

NOTE: The Day Hand will move together with the Hour Hand and Minute Hand. Keep turning the crown until the desired day has been reached.

**TO SET THE TIME:**

1. Pull crown out to second click position C.
2. Turn crown to set time.
3. Push crown back to position A.

NOTE: The 24 Hour Hand will also be set during time setting.

**TO SET THE DATE:**

1. Pull crown out to first click position B.
2. Turn crown either clockwise or counter-clockwise to set date.
3. Push crown back to position A.


NOTE: The direction of crown turning for date setting varies on different watch models.

NOTE: Do not set the date between 9:00 P.M. and 1:00 A.M. Otherwise, the date may not change properly on the following day. If it is necessary to set the date during that time period, first change the time to any time outside it, then set the date and then reset to the correct time.



## THREE-EYE MULTI-FUNCTION MODELS WITH DATE / MONTH

1. Hour Hand
2. Minute Hand
3. Second Hand
4. 24 Hour Hand /  
Second Time Zone Hand
5. Day (of the week) Hand
6. Date Window
7. Month Hand



(9232.1920)

S1. Month Set Button

S2. 24 Hour Hand / Second Time Zone Hand Set Button

### TO SET THE DAY (OF THE WEEK):

1. Pull crown out to second click position C.
2. Turn crown clockwise to set day.
3. Push crown back to position A.

NOTE: The Day Hand will move together with the Hour Hand and Minute Hand. Keep turning the crown until the desired day has been reached.

### TO SET THE TIME:

1. Pull crown out to second click position C.
2. Turn crown clockwise to set time.
3. Push crown back to position A.

NOTE: The 24 Hour Hand / Second Time Zone Hand, Day Hand and Date Window will also be set during time setting.

## **TO SET THE 24 HOUR HAND / SECOND TIME ZONE HAND (QUICK CHANGE FUNCTION):**

1. Set crown at position A.
2. Press S2 button to set the 24 Hour Hand / Second Time Zone Hand. Each press will advance the hand by 1 unit.

**NOTE:** When using S2 button to set the 24 Hour Hand / Second Time Zone Hand, the Minute Hand must be set to between 55th minute and 05th minute at any hour.

## **TO SET THE DATE (QUICK CHANGE FUNCTION):**

1. Pull crown out to first click position B.
2. Turn crown clockwise to set date.
3. Push crown back to position A.

**NOTE:** Do not use quick change function to set date between 9:00 P.M. and 00:30 A.M. Otherwise, the date may not change properly. If it is necessary to set the date during that time period, first change the time to any time outside it, then set the date and then reset to the correct time.


## **TO SET THE MONTH:**

1. Set crown at position A.
2. Press S1 button to set the Month Hand. Each press will advance the hand by 1 unit.

**NOTE:** Do not set month on the 31st of a month.

## TWO-EYE CHRONOGRAPH MODELS

1. Hour Hand
2. Minute Hand
3. Second Hand
4. Chronograph Minute Hand
5. Chronograph Second Hand
6. Date Window (Optional)



S1 – Chronograph start/stop button

S2 – Chronograph reset button

## TO ADJUST THE CHRONOGRAPH HANDS

### POSITION:

Before setting the time, check if the Chronograph Second Hand and Chronograph Minute Hand are at the zero position.

If the chronograph is in use, press the button in the following order to reset it, and then check if the chronograph hands have returned to zero position.

If the chronograph is counting:	S1 → S2
If the chronograph is stopped:	S2

In case one or several chronograph hands are not at the zero position due to certain reasons (e.g. following a battery change), that needs to be adjusted.

1. Pull crown out to second click position C.
2. Press S1 button to set the Chronograph Second Hand. Holding down the button will allow quick advance.
3. Push crown back to position A.

### **TO SET THE TIME:**

1. Pull crown out to second click position C.
2. Turn crown to set time.
3. Push crown back to position A.

### **TO SET THE DATE:**

1. Pull crown out to first click position B.
2. Turn crown counter-clockwise to set date.
3. Push crown back to position A.

**NOTE:** Do not set the date between 9:00 P.M. and 1:00 A.M. Otherwise, the date may not change properly on the following day. If it is necessary to set the date during that time period, first change the time to any time outside it, then set the date and then reset to the correct time.


**TO USE THE CHRONOGRAPH (STOPWATCH):**

For the measurement of elapsed time,

1. Press S1 button to start counting.
2. To stop counting, press S1 button once. Press S1 button again to resume from where it left off.
3. To reset to zero, press S1 button to stop counting and then press S2 button.

## THREE-EYE CHRONOGRAPH MODELS

1. Hour Hand
2. Minute Hand
3. Second Hand  
or Chronograph  
1/20 Second Hand
4. 24 Hour Hand
5. Chronograph Minute Hand
6. Chronograph Second Hand
7. Date Window (Optional)



S1 – Chronograph start/stop button

S2 – Chronograph reset button

## TO ADJUST THE CHRONOGRAPH HANDS POSITION:

Before setting the time, check if the Chronograph 1/20 Second Hand (for certain models only), Chronograph Second Hand and Chronograph Minute Hand are at the zero position.

If the chronograph is in use, press the button in the following order to reset it, and then check if the chronograph hands have returned to zero position.

If the chronograph is counting:	S1 → S2
If the chronograph is stopped:	S2

In case one or several chronograph hands are not at the zero position due to certain reasons (e.g. following a battery change), that needs to be adjusted.

1. Pull crown out to second click position C.
2. Press S1 button to set the Chronograph Second Hand. Holding down the button will allow quick advance.
3. Press S2 button to set the Chronograph 1/20 Second Hand (for certain models only). Holding down the button will allow quick advance.
4. Push crown back to position A.

### **TO SET THE TIME:**

1. Pull crown out to second click position C.
2. Turn crown to set time.
3. Push crown back to position A.

**NOTE:** The 24 Hour Hand will also be set during time setting.

### **TO SET THE DATE:**

1. Pull crown out to first click position B.
2. Turn crown counter-clockwise to set date.
3. Push crown back to position A.

**NOTE:** Do not set the date between 9:00 P.M. and 1:00 A.M. Otherwise, the date may not change properly on the following day. If it is necessary to set the date during that time period, first change the time to any time outside it, then set the date and then reset to the correct time.

**TO USE THE CHRONOGRAPH (STOPWATCH):**

Press S2 button to switch the watch to chronograph mode,


1. Press S1 button to start counting.
2. To stop counting, press S1 button once. Press S1 button again to resume from where it left off.
3. To reset to zero, press S1 button to stop counting and then press S2 button.

**NOTE:** For certain models, the chronograph is able to measure and display time in 1/20 second units up to maximum of 1 hour. The retrograde Chronograph 1/20 Second Hand keeps counting continuously for 60 seconds after starting, and then stops at zero position. When S1 button is pressed to stop the chronograph, the Chronograph 1/20 Second Hand will quickly advance to display the measured time.



## THREE-EYE CHRONOGRAPH MODELS

1. Hour Hand
2. Minute Hand
3. Second Hand
4. Chronograph  
1/10 Second Hand
5. Chronograph  
Second Hand
6. Chronograph Minute Hand
7. Date Window



S1. Chronograph start/stop button

S2. Chronograph split/split release/reset button

## TO ADJUST THE CHRONOGRAPH HANDS POSITION:

Before setting the time, check if the Chronograph 1/10 Second Hand, Chronograph Second Hand and Chronograph Minute Hand are at the zero position.

If the Chronograph is in use, press the button in the following order to reset it, and then check if the Chronograph hands have returned to zero position.

If the chronograph is counting:	S1 → S2
If the chronograph is stopped:	S2
If the split time is displayed:	S2 → S1 → S2

In case one or several Chronograph hands are not at the zero position due to certain reasons (e.g. following a battery change), that needs to be adjusted.

1. Pull crown out to second click position C.
2. Press S1 button to set the Chronograph 1/10 Second Hand. Holding down the button will allow quick advance.
3. Press S2 button to set the Chronograph Second Hand and Chronograph Minute Hand (mechanically coupled). Holding down the button will allow quick advance.
4. Push crown back to position A to set.

### **TO SET THE TIME:**

1. Pull crown out to second click position C.
2. Turn crown clockwise to set time.
3. Push crown back to position A.

**NOTE:** Make sure you have correctly set A.M./P.M. before setting the time. When the date changes over, it is A.M. (The date changes over between 9:00 P.M. and 1:00 A.M.)

### **TO SET THE DATE:**

1. Pull crown out to first click position B.
2. Turn crown clockwise to set date.
3. Push crown back to position A.

**NOTE:** Do not set the date between 9:00 P.M. and 1:00 A.M. Otherwise, the date may not change properly. If it is necessary to set the date during

that time period, first change the time to any time outside it, set the date and then reset the correct time.

### **TO USE THE CHRONOGRAPH (STOPWATCH):**

For the measurement of elapsed time,

1. Press S1 button to start counting.
2. To stop counting, press S1 button once. Press S1 button again to resume from where it left off.
3. To reset to zero, press S1 button to stop counting and then press S2 button.


For the measurement of split time,

1. Press S1 button to start counting.
2. While the Chronograph is running, press S2 button once to register a lap. The Chronograph is still running in the background.
3. To display the currently accumulated time, press S2 button again. The three Chronograph hands will quickly advance to the ongoing measured time.
4. Repeat the last step until all the laps have been registered.
5. To reset to zero, press S1 button to stop counting and then press S2 button.

**NOTE:** Chronograph 1/10 Second Hand moves for the first minute. After one minute, it indicates the measured time when it is stopped.

## THREE-EYE CHRONOGRAPH MODELS

1. Hour Hand
2. Minute Hand
3. Second Hand
4. 24 hour Hand
5. Chronograph Second Hand
6. Chronograph Minute Hand



S1 – Chronograph start/stop button

S2 – Chronograph reset button

## TO ADJUST THE CHRONOGRAPH HANDS POSITION:

Before setting the time, check if the Chronograph Second Hand and Chronograph Minute Hand are at the zero position.

If the chronograph is in use, press the button in the following order to reset it, and then check if the chronograph hands have returned to zero position.

If the chronograph is counting :	S1 → S2
If the chronograph is stopped :	S2

In case one or several chronograph hands are not at the zero position due to certain reasons (e.g. following a battery change), that needs to be adjusted.

1. Pull crown out to first click position B.
2. Press S1 button to set the Chronograph Second Hand and Chronograph Minute Hand (mechanically coupled). Holding down the button will allow quick advance.
3. Push crown back to position A.

### **TO SET THE TIME:**

1. Pull crown out to first click position B.
2. Turn crown to set time.
3. Push crown back to position A.

NOTE : The 24 Hour Hand will also be set during time setting.

### **TO USE THE CHRONOGRAPH (STOPWATCH):**

For the measurement of elapsed time.


1. Press S1 button to start counting.
2. To stop counting, press S1 button once. Press S1 button again to resume from where it left off.
3. To reset to zero, press S1 button to stop counting and then press S2 button.

NOTE : The chronograph is able to measure and display time in 1 second unit up to maximum of 29 minutes 59 seconds. The chronograph will stop automatically after running continuously for 30 minutes.

## DIGITAL WATCH WITH THREE BUTTONS

1. Hour / Month Indicator
2. Minute / Date Window

- S1 – Mode Button  
S2 – Set Button  
S3 – Light Button



### DISPLAY MODES:

The watch has two display modes: TIME and DATE.

To change from one display mode to another, press S1 button once.

**NOTE:** In setting mode, the watch will automatically return to TIME mode if there is no buttons pressed for approximately 3 seconds.

### TO SET THE TIME:

1. Press S1 button to select TIME mode.
2. Press S2 button, the hour indicator will blink. Press S1 button to set the hour indicator. Holding down the button will speed up the process.
3. Press S2 button, the minute digits will blink. Press S1 button to set the minute digits. Holding down the button will speed up the process.

4. When finished making all the settings, press S2 button to confirm.

NOTE: The hour digits are identified by “P” for  
12:00 P.M. – 11:59 P.M.


### **TO SET THE DATE:**

1. Press S1 button to select DATE mode.
2. Press S2 button, the month indicator will blink. Press S1 button to set the month indicator. Holding down the button will speed up the process.
3. Press S2 button, the date digits will blink. Press S1 button to set the date digits. Holding down the button will speed up the process.
4. When finished making all the settings, press S2 button to confirm.

### **TO USE THE BACKLIGHT:**

Press S3 button to turn on the backlight for approximately 3 seconds.

## DIGITAL WATCH WITH VERTICAL TIME DISPLAY



S1 – Mode Button

S2 – Set Button

### DISPLAY MODES:

The watch has three display modes: TIME, CALENDAR and SECONDS.

To change from one display mode to another, press S1 button once.

NOTE: In CALENDAR mode, the watch will automatically return to TIME mode if there is no buttons pressed for approximately 3 seconds.


### TO SET THE TIME AND CALENDAR:

1. Press S1 button to select TIME mode.
2. Press S2 button twice, the month digits will be displayed.
3. Press S1 button to set the month digits. Holding down the button will speed up the process.



4. Press S2 button, the date digits will be displayed.
5. Press S1 button to set the date digits.
6. Press S2 button, the hour digits, colon and A or P (representing A.M. and P.M. respectively) will be displayed.
7. Press S1 button to set the hour digits.
8. Press S2 button, colon and the minute digits will be displayed.
9. Press S1 button to set the minute digits.
10. Press S2 button, the hour digits, colon and the minute digits will be displayed.
11. When finished making all the settings, press S1 button to confirm. The colon will blink.

## DIGITAL WATCH



S1 – Mode Button

S2 – Set Button

### DISPLAY MODES:

The watch has three display modes: TIME, CALENDAR and SECONDS.

To change from one display mode to another, press S1 button once.

NOTE: In CALENDAR mode, the watch will automatically return to TIME mode if there is no buttons pressed for approximately 3 seconds.

### TO SET THE TIME AND CALENDAR:

1. Press S1 button to select TIME mode.
2. Press S2 button twice, the month digits will be displayed.
3. Press S1 button to set the month digits. Holding down the button will speed up the process.
4. Press S2 button, the date digits will be displayed.
5. Press S1 button to set the date digits.

6. Press S2 button, the hour digits, colon and A or P (representing A.M. and P.M. respectively) will be displayed.
7. Press S1 button to set the hour digits.
8. Press S2 button, colon and the minute digits will be displayed.
9. Press S1 button to set the minute digits.
10. Press S2 button, the hour digits, colon and the minute digits will be displayed.
11. When finished making all the settings, press S1 button to confirm. The colon will blink.

### **TO SET THE SECONDS:**

1. Press S1 button to select SECONDS mode.
2. Press S2 button to reset the second digits to zero.


## DIGITAL WATCH

S1 – Start/Stop Button

S2 – Lap/Reset Button

S3 – Mode Button

S4 - Light Button



### DISPLAY MODES:

The watch has four display modes: NORMAL TIME, CALENDAR, ALARM and STOPWATCH.

In NORMAL TIME mode, press and hold S1 button to display the CALENDAR, or press and hold S2 button to display the ALARM.

Press S3 button to toggle between NORMAL TIME mode and STOPWATCH mode.

### TO SET THE TIME AND CALENDAR:

1. Press S3 button to select NORMAL TIME mode.
2. Press and hold S3 button for approximately 3 seconds, then release and press S3 button again. The Tuesday indicator and the second digits will blink.
3. Press S2 button to reset the second digits to zero. This will increase the time by 1 minute if the original setting is at 30 to 59 seconds.
4. Press S1 button, the minute digits will blink.

5. Press S2 button to set the minute digits. Holding down the button will speed up the process.
6. Press S1 button, the hour digits will blink.
7. Press S2 button to set the hour digits. Holding down the button will speed up the process.
8. Follow the same pattern to set the month, date and day (of the week).
9. When finished making all the settings, press S3 button to confirm.

### **TO SET THE HOUR FORMAT:**

In NORMAL TIME mode, press and hold S2 button, then press S3 button to toggle between 12-hour and 24-hour format. The "A" indicator will be displayed to indicate the watch is in 12-hour format.

After setting to 12-hour format, the P.M. indicator will be displayed to indicate the time period 12:00P.M.-11:59P.M. in NORMAL TIME mode.

### **TO SET THE CALENDAR FORMAT:**

In NORMAL TIME mode, press and hold S1 button, then press S2 button to toggle between month-date and date month format.

### **TO SET THE ALARM:**

In NORMAL TIME mode,



1. Press and hold S3 button for approximately 3 seconds. The Monday indicator and the hour digits will blink.

2. Press S2 button to set the hour digits. Holding down the button will speed up the process.
3. Press S1 button, the minute digits will blink.
4. Press S2 button to set the minute digits. Holding down the button will speed up the process.
5. When finished making all the settings, press S3 button to confirm.

NOTE: The alarm will automatically be activated after being set.

## **TO TURN ON/OFF THE ALARM AND HOURLY CHIME:**

In NORMAL TIME mode,

1. Press and hold S2 button and then press S1 button once to activate the hourly chime. The chime indicator  will appear.
2. Press again to active the alarm. The alarm indicator  will appear.
3. Press the third time to deactivate the hourly chime. The chime indicator will disappear.
4. Press the fourth time to deactivate the alarm. The alarm indicator will disappear.

## **WHEN AN ALARM OR HOURLY CHIME GOES OFF:**

A tune will be emitted by the hour when the hourly chime function is activated.

An alarm tune will be emitted at the designated time

when the alarm is activated. To stop the tune, press S2 button.

## **TO USE THE STOPWATCH:**

1. Press S3 button to select STOPWATCH mode.
2. The stopwatch will then be displayed in its current state – stopped, running or reset.
3. To resume a stopped counting, press S1 button to resume from where it left off.
4. To start a new counting, reset the stopwatch to zero first.  
Press S1 button to stop counting, then press S2 button to reset counter to zero.

For the measurement of elapsed time:

In STOPWATCH mode,

1. Press S1 button to start counting.
2. To stop counting, press S1 button once. Press S1 button again to resume from where it left off.
3. To reset to zero, press S1 button to stop counting and then press S2 button.

For the measurement of split time:

In STOPWATCH mode,

1. Press S1 button to start counting.
2. While the stopwatch is running, press S2 button once to register a lap. The split time of the registered lap will be displayed. The stopwatch is still running in the background.

To display the current elapsed time, press S2 button again.

3. Repeat the last step until all the laps have been registered.
4. To reset to zero, press S1 button to stop counting and then press S2 button.

For the measurement of two finishes:

In STOPWATCH mode,

1. Press S1 button to start counting.
2. While the stopwatch is running, press S2 button to register and display the time of the first runner. The stopwatch is still running in the background.
3. Press S1 button to stop and register the time of the second runner.
4. Press S2 button to display the time of the second runner.
5. To reset to zero, press S2 button again.

NOTE: You can leave the stopwatch running while switching over to other operating modes.

### **TO USE THE BACKLIGHT:**

Press S4 button to turn on the backlight for approximately 3 seconds.



## DIGITAL CHRONOGRAPH WITH ALARM




- A. START/STOP
- B. LAP/RESET
- C. MODE
- D. LIGHT

A beep will be emitted to register successful entry when A or B button is pressed in Chronograph and Timer mode.

### DISPLAY MODES:

The watch has five display modes: Time Keeping, Chronograph, Recall, Alarm and Timer.



To change one display mode in the sequence of: Time Keeping, Chronograph, Recall, Alarm and Timer, press the C button once.

There is an animated banner display in all modes. This animation can be skipped by pressing buttons A, B or C.

## BUTTONS OPERATION

MODE	DESCRIPTION	A	B	C	D
		START/STOP	LAP/RESET	MODE	LIGHT
TIME	PRESS-RELEASE	--	HOLD TO SET	TO CHRONO	LIGHT ON
	PRESS & HOLD	--	SETTING	--	LIGHT ON
CHRONO	PRESS-RELEASE	START/STOP	LAP/HOLD TO RESET	TO RECALL	LIGHT ON
	PRESS & HOLD	--	CLEAR	--	LIGHT ON
RECALL	PRESS-RELEASE	VIEW NEXT	VIEW TOTAL	TO ALARM	LIGHT ON
	PRESS & HOLD	--	--	--	LIGHT ON
ALARM	PRESS-RELEASE	ALARM ON/OFF	HOLD TO SET	TO TIMER	LIGHT ON
	PRESS & HOLD	--	SETTING	--	LIGHT ON
TIMER	PRESS-RELEASE	START/STOP	RESET/HOLD TO SET	TO TIME	LIGHT ON
	PRESS & HOLD	--	SETTING	--	LIGHT ON

SETTING	DESCRIPTION	A	B	C	D
		START/STOP	LAP/RESET	MODE	LIGHT
ALL	PRESS-RELEASE	INCREMENT	NEXT ITEM	DECREMENT	LIGHT ON
	PRESS & HOLD	FAST ADVANCE	--	FAST ADVANCE	LIGHT ON


### TO TURN ON THE BACKLIGHT:

In any mode, press the D button to turn on the backlight for 6 seconds and press any button if the backlight on, backlight will turn on 6 seconds more after releasing the button.

**NOTE:** Continual use of backlight will result in significant consumption of the battery power. This will reduce the normal battery life time to less than 1 year.

## TO SET THE TIME AND DATE:

1. Press C button to change in Time Keeping mode.
2. Press the B button, "HOLD TO SET" will display and hold it 3 seconds, the second digits will blink.
3. Press B button to change the selection in the following sequence:



The selection digits will blink while they are selected.

4. While the following parameters are selected,

**Seconds:** Press A or C button to reset the second digits to zero.

**Minutes, Hours, Date, Month, Year:** Press A button once to increase or C button once to decrease the digits by one unit. Holding either button will increase or decrease the value at high speed.

**12/24-Hour Format:** Press A or C button to select between 12-hour format with AM or PM indicator and 24-hour format.

**Date Format:** Press A or C button to select between MM-DD for month-day format and DD-MM for day-month format.

5. After making all the settings, return to current time display (No digits blink).
- If no button is operated for 2-3 minutes while a selection is blinking, the watch goes back to the Time Keeping Mode automatically.
- The day can be set within the range of 1 January 2000 to 31 December 2099.
- The day of week is automatically set in accordance with the date.


### **TO USE THE CHRONOGRAPH:**

For a straight forward count-up,

1. Press the C button to select Chronograph mode.
2. If the last recorded time of the Chronograph will be displayed, press and hold the B button to clear the old record.
3. Press the A button once to start the Chronograph. The watch will start counting from 00'00''00 if the watch is cleared. Otherwise, it will pick up from where it last left off.
4. To stop counting, press the A button once. Press the A button again to resume from where it left off.
5. To clear the Chronograph, press the A button to stop counting and then Press the B button, "HOLD TO RESET" will display and hold the same button until 00.0000 displays.

The Chronograph is equipped with a split function for you to keep track of individual lap time. To use the function,

1. While the Chronograph is running, press the B button once whenever you want to register a lap. The lap time will be saved (first 10 laps) and the lap number will be displayed on top. The Chronograph is still running on next lap in the background, it will display the currently running lap time after 4 seconds.
2. Repeat the last step until you have registered all the laps. Only the first 10-lap time will be recorded. But you can register up to 100 laps. The lap number will be automatically generated. After 100 laps, the lap number will not be generated.
3. Press A to stop counting. Press the button again to resume or press and hold the B button to clear.  
The range of the Chronograph is 99 hours, 59 minutes and 59.99 seconds.

**NOTE:** You can leave the chronograph running while switching over to other operating modes. The  will light up as a reminder in Time Keeping Mode.

## **TO CHECK LAP RECORDS IN RECALL MODE:**

You can check the lap records in Recall mode.

1. Use the C button to select Recall mode. The first lap record will be displayed. The Recall indicator will appear.
2. Press A button once to view next lap records and press

B button once to view total accumulated time record. If chronograph is still running, total accumulated time record cannot be viewed.

The lap records will be suppressed and replaced when a new chronograph begins.

## TO SET THE ALARM:

1. Press the C button to select Alarm mode.
2. Press and hold the B button, "HOLD TO SET" will display after 3 seconds and the minute digits will blink.
3. Press B button to change the selection in the following sequence:



The selection digits will blink while they are selected.



4. While any digits are selected, press A button once to increase or C button once to decrease the digits by 1 unit. Holding either button will increase or decrease the value at high speed.

Hour format of alarm time is dictated by the one selected for Time Keeping.

5. When finished making all the settings, return to the Alarm Mode. The alarm function will be turn on automatically even there is no change in the setting.

If no button is operated for 2-3 minutes while a selection is blinking, the watch goes back to the Alarm Mode automatically.

## TO SET THE ALARM ON/OFF:

1. Press the C button to select Alarm mode.
2. Press the A button once to activate the alarm.  
 appears.
3. Press the button again to deactivate the alarm function.  
 disappears.

## WHEN AN ALARM GOES OFF:

A 20 second alarm tune will be emitted at the designated time when the alarm is active. To stop either tune, press A, B or C button without function or D button with backlight function.

## TO SET THE COUNTDOWN-TIMER:

1. Press the C button to select Timer mode.
2. Press the B button, "HOLD TO SET" will display and hold it 3 seconds, the second digits will blink.
3. Press B button to change the selection in the following sequence:



The selection digits will blink while they are selected.

4. While any digits are selected, press A button once to increase or C button once to decrease the digits by one unit. Holding either button will increase or decrease the value at high speed.

5. When finished making all parameter settings, return the Timer Mode.
  - If Timer value is set to zero, cannot start the timer.
  - You can set the timer from 0 hour, 00 minute and 00 second to 23 hours, 59 minutes. 59 seconds.
  - If no button is operated for 2-3 minutes while a selection is blinking, the watch goes back to the Alarm Mode automatically.


### **TO USE THE COUNTDOWN-TIMER:**

To start a countdown, press the A button. Press the button again to stop the countdown or a third time to resume from where it left off.

To return preset time, press the A button to stop counting and then press the B button.

After reaching zero on a countdown, the timer will count-up and a 10-second beep will go off. To stop the beeping, press A, B or C button without function or D button with backlight function.

The range of the Count-up Timer is 23 hours, 59 minutes and 59 seconds.


Note: You can leave the timer running while switching over to other operating modes. The  will light up as a reminder in Time Keeping Mode.



## DIGITAL CHRONOGRAPH WITH WORLD TIME

S1– Mode Button

S2– Set Button



(G0601A)

### DISPLAY MODES:

The watch has four display modes: NORMAL TIME, ALARM, CHRONOGRAPH and WORLD TIME.

To change from one display mode to another, press S1 button once.

NOTE: Display screen will be off if there is no buttons pressed for 8 seconds. Press any button can turn it on again.

### TO SET THE TIME AND CALENDAR:



1. Press S1 button to select NORMAL TIME mode.
2. Press and hold S1 button for 3 seconds to enter into setting mode.
3. The Daylight Saving Time setting will be selected. Press S2 button to toggle between on and off.
4. Press S1 button again, the hour digits will be selected.

5. Press S2 button to set the hour digits. Holding down the button will speed up the process.
6. Press S1 button, the minute digits will be selected.
7. Press S2 button to set the minute digits. Holding down the button will speed up the process.
8. Press S1 button, the second digits will be selected.
9. Press S2 button to reset the second digits to zero.
10. Press S1 button, the hour format will be selected.
11. Press S2 button to toggle between 12-hour and 24-hour format. The A or P indicator will be displayed to indicate the time period 12:00A.M.–11:59A.M. or 12:00P.M.–11:59P.M. respectively in 12-hour format.
12. Follow the same pattern to set the year, month, date, calendar format and city selection.
13. To set the city selection, press S2 button to scroll through the 32 preset cities.
14. When finished making all the settings, press S1 button to confirm.

NOTE: The selected hour and calendar formats will apply to both NORMAL TIME mode and WORLD TIME mode.

## TO TURN ON/OFF THE BUTTON BEEP:





In NORMAL TIME mode,

1. Press and hold S2 button for 3 seconds to activate the button beep. Button beep indicator  will appear.
2. Press and hold S2 button for 3 seconds again to deactivate the button beep. Button beep indicator  will disappear.

## TO SET THE ALARM TIME:

1. Press S1 button to select ALARM mode.
2. Press and hold S1 button for 3 seconds, the hour digits will be selected.
3. Press S2 button to set the hour digits. Holding down the button will speed up the process.
4. Press S1 button, the minute digits will be selected.
5. Press S2 button to set the minute digits. Holding down the button will speed up the process.
6. When finished making all the settings, press S1 button to confirm.

## TO TURN ON/OFF THE ALARM AND HOURLY CHIME:

1. In NORMAL TIME mode, press S2 button to activate the hourly chime. Chime indicator  will appear.
2. Press S2 button again to deactivate the hourly chime. Chime indicator  will disappear.
3. In ALARM mode, press S2 button to activate the daily alarm. Alarm indicator  will appear in Normal Time mode.
4. Press S2 button again to deactivate the daily alarm. Alarm indicator  will disappear in Normal Time mode.

## WHEN AN ALARM GOES OFF:

An alarm tune will be emitted at the designated time when the alarm is activated. To stop the tune, press any button.


## TO USE THE CHRONOGRAPH:

1. Press S1 button to select CHRONOGRAPH mode.

2. The chronograph will then be displayed in its current state – reset, running, or stopped.
3. To resume a counting, press S2 button to resume from where it left off.
4. To start a new counting, reset the chronograph to zero first.  
Press S2 button to stop counting, then press and hold S1 button for 3 seconds to reset the counter to zero.

For the measurement of elapsed time,  
In CHRONOGRAPH mode,

1. Press S2 button to start counting.
2. To stop counting, press S2 button. Press S2 button again to resume from where it left off.
3. To reset to zero, press S2 button to stop counting and then press and hold S1 button for 3 seconds.

NOTE: You can leave the chronograph running while switching over to other operating modes. The chronograph indicator  will blink in NORMAL TIME mode when the chronograph is in use.

## **TO SELECT THE WORLD TIME CITY AND DISPLAY ITS TIME:**

1. Press S1 button to select WORLD TIME mode.
2. Press S2 button to scroll through the city selection.
3. Press and hold S2 button for 3 seconds to toggle between Daylight Saving Time (DST) and Standard Time.

## World Time City Code Reference Table

GMT Differential	City Code	City	Other major cities in the same time zone
-11	PPG	PAGO PAGO	-----
-10	HNL	HONOLULU	PAPEETE
-9	ANC	ANCHORAGE	NOME
-8	YVR	VANCOUVER	LAS VEGAS, SEATTLE, DAWSON CITY, SAN FRANCISCO
	LAX	LOS ANGELES	
-7	DEN	DENVER	EL PASO, EDMONTON
-6	MEX	MEXICO CITY	HOUSTON, DALLAS/FORT WORTH, NEW ORLEANS, WINNIPEG
	CHI	CHICAGO	
-5	MIA	MIAMI	MONTREAL, DETROIT, BOSTON, PANAMA, CITY, HAVANA, LIMA, BOGOTA
	NYC	NEW YORK	
-4	CCS	CARACAS	LA PAZ, SANTIAGO, PORT OF SPAIN
-3	RIO	RIO DE JANEIRO	SAO PAULO, BUENOS AIRES, BRASILIA, MONTEVIDEO
+0	LON	LONDON	DUBLIN, LISBON, CASABLANCA, DAKAR, ABIDJAN
+1	PAR	PARIS	MILAN, FRANKFURT, AMSTERDAM, VIENNA, ALGIERS, STOCKHOLM, HAMBURG
	MAD	MADRID	
	ROM	ROME	
	BER	BERLIN	

+2	IST	ISTANBUL	ATHENS, HELSINKI, BEIRUT, DAMASCUS, CAPE TOWN, JERUSALEM
	CAI	CAIRO	
+3	MOW	MOSCOW	KUWAIT, RIYADH, ADEN, ADDIS ABABA, NAIROBI
+4	DXB	DUBAI	ABU DHABI, MUSCAT
+5	KHI	KARACHI	-----
+5.5	DEL	DELHI	MUMBAI, KOLKATA
+6	DAC	DHAKA	-----
+7	BKK	BANGKOK	JAKARTA, PHNOM PENH, HANOI, VIENTIANE
+8	SIN	SINGAPORE	KUALA LUMPUR, TAIPEI, PERTH, BEIJING, MANILA, ULAANBAATAR
	HKG	HONG KONG	
+9	TYO	TOKYO	PYONGYANG, SEOUL
+10	GUM	GUAM	MELBOURNE, RABAUL
	SYD	SYDNEY	
+11	NOU	NOUMEA	PORT VILA
+12	WLG	WELLINGTON	CHRISTCHURCH, NADI, NAURU ISLAND

## DIGITAL WATCH WITH TOUCH SENSOR TECHNOLOGY AND PUSH BUTTON ACTIVATION

- S1. Start/Stop sensor
- S2. Set/reset sensor
- S3. Mode sensor
- S4. Light sensor
- S5. Touch sensor unlock button



### TO LOCK AND UNLOCK THE TOUCH SENSORS:

There are 4 touch sensors around the lens of the watch (S1,S2,S3,and S4). To unlock the sensors, press S5 button. The touch sensor indicator (T) will be displayed to indicate the touch sensors are unlocked.

When no sensors are pressed for 10 seconds, the touch sensor lock will automatically be activated (except in CHRONOGRAPH mode and TIMER mode when the chronograph or timer is in use) and the touch sensors will be locked.

### DISPLAY MODES:

The watch has five display modes: NORMAL TIME, WORLD TIME (WT), ALARM (AL), CHRONOGRAPH (CR) and TIMER (TR).

To change from one display mode to another, press S3 sensor once.

**NOTE:** In any setting mode, when there is no sensor pressed for 30 seconds, the watch will automatically save the entered data and exit the setting procedure.

## **TO SET THE TIME AND CALENDAR:**

1. Press S3 sensor to select NORMAL TIME mode.
2. Press and hold S2 sensor, the message "HOLD TO SET" will be displayed for 2 seconds and the local city selection will blink. Press S1 or S2 sensor to cycle forward or backward through the 32 preset cities/ time zones to select your home city for display in NORMAL TIME.
3. Press S3 sensor, the Daylight Savings Time (DST) setting will blink. Press S1 or S2 sensor to toggle between ON and OFF of the DST setting. Note that setting DST for NORMAL TIME does not automatically apply to the same city in WORLD TIME. You must apply DST to WORLD TIME cities separately.
4. Press S3 sensor, the hour digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value. Holding down the sensor will speed up the process.
5. Press S3 sensor, the minute digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value. Holding down the sensor will speed up the process.
6. Press S3 sensor, the second digits will blink. Press S1 or S2 sensor to reset the second digits to zero.
7. Press S3 sensor, the year digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value. Holding down the sensor will speed up the process.
8. Press S3 sensor, the month digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value. Holding down the sensor will speed up the process.
9. Press S3 sensor, the date digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value. Holding down the sensor will speed up the process.
10. Press S3 sensor, the hour format setting will blink. Press S1 or S2 sensor to toggle between 12-hour and 24-hour format. The P.M. indicator may be displayed to indicate the time period 12:00 P.M. – 11:59 P.M. in 12-hour format.



11. Press S3 sensor, the “BEEP” setting will blink. The “BEEP” option will cause the watch to beep anytime a sensor or button is pressed. Press S1 or S2 sensor to toggle between ON and OFF for the beep setting.
12. Press S3 sensor, the hourly chime (CHIME) setting will blink. Press S1 or S2 sensor to toggle between ON and OFF for the hourly chime setting.
13. When finished making all the settings, press and hold S3 sensor for approximately 3 seconds to confirm.

NOTE: The day (of the week) is automatically set in accordance with the date. The date can be set within the range of 1 January 2009 to 31 December 2099.

NOTE: The selected hour format will apply to both NORMAL TIME mode and WORLD TIME mode.

## **TO SELECT AND DISPLAY THE TIME OF WORLD TIME CITY IN WORLD TIME MODE:**

1. Press S3 sensor to select WORLD TIME mode.
2. To make the world time city selection, press S1 or S2 sensor to cycle forward or backward through the 32 preset cities / time zones.
3. Press and hold S1 sensor for approximately 3 seconds to toggle between DST and Standard Time. The DST indicator **DST** will be displayed when Daylight Savings Time is displayed.

NOTE: When you have applied DST for individual cities / time zones, the respective time will be adjusted forward by 1 hour. Please make sure you have correctly applied DST for the selected local city and world time cities with reference to information available on the Internet, or else the watch will not be able to display the time of individual cities / time zones properly.

## WORLD TIME CITY CODE REFERENCE TABLE:

	GMT Differential	City Code	City	Other major cities in the same time zone
1	-11	PPG	PAGO PAGO	-----
2	-10	HNL	HONOLULU	PAPEETE
3	-9	ANC	ANCHORAGE	NOME
4	-8	YVR	VANCOUVER	LAS VEGAS, SEATTLE, DAWSON CITY, SAN FRANCISCO
5		LA	LOS ANGELES	
6	-7	DEN	DENVER	EL PASO, EDMONTON
7	-6	ME	MEXICO CITY	HOUSTON, DALLAS/ FORT WORTH, NEW ORLEANS, WINNIPEG
8		CHI	CHICAGO	
9	-5	MIA	MIAMI	MONTREAL, DETROIT, BOSTON, PANAMA CITY, HAVANA, LIMA, BOGOTA
10		NYC	NEW YORK	
11	-4	SAN	SANTIAGO	LA PAZ, PORT OF SPAIN
12	-3	RIO	RIO DE JANEIRO	SAO PAULO, BUENOS AIRES, BRASILIA, MONTEVIDEO
13	+0	LON	LONDON	DUBLIN, LISBON, CASABLANCA, DAKAR, ABIDJAN
14	+1	PAR	PARIS	MILAN, FRANKFURT, AMSTERDAM, VIENNA, AL GIERS, STOCKHOLM, HAMBURG
15		MAD	MADRID	
16		ROM	ROME	
17		BER	BERLIN	

18	+2	IST	ISTANBUL	ATHENS, HELSINKI, BEIRUT, DANASCUS, CAPE TOWN, JERUSALEM
19		CAI	CAIRO	
20	+3	MOW	MOSCOW	KUWAIT, RIYADH, ADEN, ADDIS ABABA, NAIROBI
21	+4	DBI	DUBAI	ABU DHABI, MUSCAT
22	+5	KHI	KARACHI	-----
23	+5.5	DEL	DELHI	MUMBAI, KOLKATA
24	+6	DAC	DACCA	-----
25	+7	BKK	BANGKOK	JAKARTA, PHNOM PENH, HANOI, VIENTIANE
26	+8	SIN	SINGAPORE	KUALA LUMPUR, TAIPEI, PERTH, BEIJING, MANILA, ULAANBAATAR
27		HKG	HONG KONG	
28	+9	TYO	TOKYO	PYONGYANG, SEOUL
29	+10	GUM	GUAM	MELBOURNE, RABAU
30		SYD	SYDNEY	
31	+11	NOU	NOUMEA	PORT VILA
32	+12	WLG	WELLINGTON	CHRISTCHURCH, NADI, NAURU ISLAND


## TO SET THE ALARM TIME:

1. Press S3 sensor to select ALARM mode.
2. Press and hold S2 sensor, the message "HOLD TO SET" will be displayed for approximately 2 seconds and the hour digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value. Holding down the sensor will speed up the process.

3. Press S3 sensor, the minute digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value. Holding down the sensor will speed up the process.
4. When finished making all the settings, press and hold S3 sensor for approximately 3 seconds to confirm.

NOTE: The alarm will automatically be activated after being set.

### **TO TURN ON/OFF THE ALARM:**

In ALARM mode, press S1 sensor to toggle between ON and OFF of the alarm. When the alarm is ON, the alarm indicator  will appear.

### **WHEN AN ALARM GOES OFF:**


An alarm tune will be emitted at the designated time when the alarm is activated. To stop the tune, press any sensor or button.

### **TO USE THE CHRONOGRAPH:**

1. Press S3 sensor to select CHRONOGRAPH mode.
2. For the measurement of elapsed time in CHRONOGRAPH mode , press S1 sensor to start counting.
3. To stop counting, press S1 sensor.
4. To restart counting to resume from where it left off , press S1 sensor again.
5. To reset to zero, press S1 sensor to stop counting and then press S2 sensor.

NOTE: The touch sensor lock will not be activated in CHRONOGRAPH mode when the chronograph is in use.

NOTE: The chronograph can count up to a maximum of 23 hours, 59 minutes and 59.99 seconds

NOTE: You can leave the chronograph running while switching over to other operating modes. The chronograph indicator  will be displayed in NORMAL TIME mode and WORLD TIME mode when the chronograph is in use.

## TO SET THE TIMER:

1. Press S3 sensor to select TIMER mode.
2. Press and hold S2 sensor, the message "HOLD TO SET" will be displayed for approximately 2 seconds and the hour digits will blink.  
Press S1 sensor to increase or S2 sensor to decrease the value. Holding down the sensor will speed up the process.
3. Press S3 sensor, the minute digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value. Holding down the sensor will speed up the process.
4. Press S3 sensor, the second digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value. Holding down the sensor will speed up the process.
5. Press S3 sensor, the "Action-at-End\*" setting will blink. Press S1 or S2 sensor to toggle between STOP AT END and REPEAT AT END.
6. When finished making all the settings, press and hold S3 sensor for 3 seconds to confirm.



NOTE\* : Action-at -END setting option definitions:

- a) STOP AT END – the timer will stop when the countdown reaches zero.
- b) REPEAT AT END – the timer will repeat the countdown when the countdown reaches zero.

## TO USE THE TIMER:

1. Press S3 sensor to select TIMER mode.
2. To start a new counting, press S1 sensor.
3. To stop counting, press S1 sensor.
4. To resume a counting from where it left off, press S1 sensor to restart.
5. To reset timer: If counting is stopped press S2 sensor; If counting is running, press S1 sensor to stop and then press S2 sensor to reset the count.
6. Upon completion of a countdown, if STOP AT END is selected as the action to be taken, the timer stops at zero and a beep (for timer of less than 30 seconds) / tune (for time of 30 seconds or more).

NOTE: The touch sensor lock will not be activated in TIMER mode when the timer is in use.

NOTE: You can leave the timer running while switching over to other operating modes. The timer indicator  (STOP AT END) /  (REPEAT AT END) will be displayed in NORMAL TIME mode and WORLD TIME mode when the timer is in use.

## TO USE THE BACKLIGHT:

Press S4 sensor to turn on the backlight for 3 seconds.

NOTE: Continual use of backlight will result in significant consumption of the battery power. This will reduce the normal battery life time to less than 1 year.

## DIGITAL WATCH WITH TOUCH SENSOR TECHNOLOGY

- S1. Start/stop sensor
- S2. Set/reset sensor
- S3. Mode sensor
- S4. Light sensor



### TO LOCK AND UNLOCK THE TOUCH SENSORS:

There are 4 touch sensors around the lens of the watch (S1, S2, S3 and S4). To unlock the sensors, press and hold S4 sensor for approximately 1 second, then slide on the lens from S4 sensor to S2 sensor in clockwise direction. The touch sensor indicator **T** will be displayed to indicate the touch sensors are unlocked.

When no sensors are pressed for 10 seconds, the touch sensor lock will automatically be activated (except in CHRONOGRAPH mode and TIMER mode when the chronograph or timer is in use) and the touch sensors will be locked.

### DISPLAY MODES:

The watch has four display modes: NORMAL TIME, ALARM (AL), CHRONOGRAPH (CH) and TIMER (TR).

To change from one display mode to another, press S3 sensor once.

**NOTE:** In any setting mode, when there is no sensor pressed for 30 seconds, the watch will automatically save the entered data and exit the setting procedure.

**NOTE:** In any setting mode, press S1 sensor for increasing the designated value or cycling forward the available options. For rapid setting, slide on the lens from S1 sensor through all 4

sensors in clockwise direction. Press S2 sensor for decreasing the designated value or cycling backward the available options. For rapid setting, slide on the lens from S2 sensor through all 4 sensors in counter-clockwise direction.

## **DISPLAY FORMATS OF NORMAL TIME MODE:**

The NORMAL TIME mode has 5 display formats: DATE/TIME, BIG TIME, DIGITAL ANALOG, DIGITAL CLOCK and WORLD TIME.

Slide from S1 sensor to S2 sensor or vice versa to cycle forward or backward through the 5 display formats.

## **TO SET THE TIME AND CALENDAR:**

1. Press S3 sensor to select NORMAL TIME mode.
2. Press and hold S2 sensor, the message "HOLD TO SET" will be displayed for approximately 2 seconds and the local city selection will blink. Press S1 or S2 sensor to cycle forward or backward through the 32 preset cities / time zones to select your home city for display in NORMAL TIME.
3. Press S3 sensor, the Daylight Savings Time (DST) setting will blink. Press S1 or S2 sensor to toggle between ON and OFF of the DST setting. Note that setting DST for NORMAL TIME does not automatically apply to the same city in WORLD TIME. You must apply DST to WORLD TIME cities separately.
4. Press S3 sensor, the hour digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value.
5. Press S3 sensor, the minute digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value.
6. Press S3 sensor, the second digits will blink. Press S1 or S2 sensor to reset the second digits to zero.
7. Press S3 sensor, the year digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value.
8. Press S3 sensor, the month digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value.
9. Press S3 sensor, the date digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value.



10. Press S3 sensor, the hour format setting will blink. Press S1 or S2 sensor to toggle between 12-hour and 24-hour format. The P.M. indicator may be displayed to indicate the time period 12:00 P.M. – 11:59 P.M. in 12-hour format.
11. Press S3 sensor, the “BEEP” setting will blink. The “BEEP” option will cause the watch to beep anytime a sensor is pressed. Press S1 or S2 sensor to toggle between ON and OFF for the beep setting.
12. Press S3 sensor, the hourly chime (CHIME) setting will blink. Press S1 or S2 sensor to toggle between ON and OFF for the hourly chime setting.
13. When finished making all the settings, press and hold S2 sensor for approximately 2 seconds to confirm.

NOTE: The day (of the week) is automatically set in accordance with the date. The date can be set within the range of 1 January 2000 to 31 December 2099.

NOTE: The selected hour format will apply to both NORMAL TIME mode and WORLD TIME mode.

## **TO SELECT AND DISPLAY THE TIME OF WORLD TIME CITY IN WORLD TIME MODE:**

1. Press S3 sensor to select NORMAL TIME mode.
2. Slide from S1 sensor to S2 sensor or vice versa to select WORLD TIME display mode.
3. To make the world time city selection, slide from S2 sensor to the 6 o'clock position of the lens or vice versa to cycle forward or backward through the 32 preset cities / time zones.
4. Press and hold S1 sensor for approximately 2 seconds to toggle between DST and Standard Time. The DST indicator will be displayed when Daylight Savings Time is displayed.

NOTE: When you have applied DST for individual cities / time zones, the respective time will be adjusted forward by 1 hour. Please make sure you have correctly applied DST for the selected local city and world time cities with reference to information available on the Internet, or else the watch will not be able to display the time of individual cities / time zones properly.

## WORLD TIME CITY CODE REFERENCE TABLE:

	GMT Differential	City Code	City	Other major cities in the same time zone
1	-11	PPG	PAGO PAGO	-----
2	-10	HNL	HONOLULU	PAPEETE
3	-9	ANC	ANCHORAGE	NOME
4	-8	VAN	VANCOUVER	LAS VEGAS, SEATTLE, DAWSON CITY, SAN FRANCISCO
5		LA	LOS ANGELES	
6	-7	DEN	DENVER	EL PASO, EDMONTON
7	-6	MEX	MEXICO CITY	HOUSTON, DALLAS/ FORT WORTH, NEW ORLEANS, WINNIPEG
8		CHI	CHICAGO	
9	-5	MIA	MIAMI	MONTREAL, DETROIT, BOSTON, PANAMA CITY, HAVANA, LIMA, BOGOTA
10		NYC	NEW YORK	
11	-4	SAN	SANTIAGO	LA PAZ, PORT OF SPAIN
12	-3	RIO	RIO DE JANEIRO	SAO PAULO, BUENOS AIRES, BRASILIA, MONTEVIDEO
13	+0	LON	LONDON	DUBLIN, LISBON, CASABLANCA, DAKAR, ABIDJAN
14	+1	PAR	PARIS	MILAN, FRANKFURT, AMSTERDAM, VIENNA, AL GIERS, STOCKHOLM, HAMBURG
15		MAD	MADRID	
16		ROM	ROME	
17		BER	BERLIN	

18	+2	IST	ISTANBUL	ATHENS, HELSINKI, BEIRUT, DANASCUS, CAPE TOWN, JERUSALEM
19		CAI	CAIRO	
20	+3	MOW	MOSCOW	KUWAIT, RIYADH, ADEN, ADDIS ABABA, NAIROBI
21	+4	DBI	DUBAI	ABU DHABI, MUSCAT
22	+5	KHI	KARACHI	-----
23	+5.5	DEL	DELHI	MUMBAI, KOLKATA
24	+6	DAC	DACCA	-----
25	+7	BKK	BANGKOK	JAKARTA, PHNOM PENH, HANOI, VIENTIANE
26	+8	SIN	SINGAPORE	KUALA LUMPUR, TAIPEI, PERTH, BEIJING, MANILA, ULAANBAATAR
27		HKG	HONG KONG	
28	+9	TYO	TOKYO	PYONGYANG, SEOUL
29	+10	GUM	GUAM	MELBOURNE, RABAU
30		SYD	SYDNEY	
31	+11	NOU	NOUMEA	PORT VILA
32	+12	WLG	WELLINGTON	CHRISTCHURCH, NADI, NAURU ISLAND

## TO SET THE ALARM TIME:

1. Press S3 sensor to select ALARM mode.
2. Press and hold S2 sensor, the message "HOLD TO SET" will be displayed for approximately 2 seconds and the hour digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value.
3. Press S3 sensor, the minute digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value.

4. When finished making all the settings, press and hold S2 sensor for approximately 2 seconds to confirm.

NOTE: The alarm will automatically be activated after being set.

### **TO TURN ON/OFF THE ALARM:**

In ALARM mode, press S1 sensor to toggle between ON and OFF of the alarm. When the alarm is ON, the message “on” will be displayed, and the alarm indicator  will be displayed in DATE/TIME, BIG TIME and WORLD TIME display formats of NORMAL TIME mode as a reminder.

### **WHEN AN ALARM GOES OFF:**

A 20-second alarm tune will be emitted at the designated time when the alarm is activated.

If the alarm is done without any user interruption, the watch will automatically enter into a snooze mode. The alarm will go off again after 20 seconds. If the alarm is again done without any user interruption, the alarm will go off again after another 20 seconds.


When the alarm tune is being emitted, press any sensor to stop the tune and terminate the snooze function.

### **TO USE THE CHRONOGRAPH:**

1. Press S3 sensor to select CHRONOGRAPH mode.
2. For the measurement of elapsed time in CHRONOGRAPH mode, press S1 sensor to start counting.
3. To stop counting, press S1 sensor.
4. To restart counting to resume from where it left off, press S1 sensor again.
5. To reset to zero, press S1 sensor to stop counting and then press S2 sensor.

NOTE: The touch sensor lock will not be activated in CHRONOGRAPH mode when the chronograph is in use.

NOTE: The chronograph can count up to a maximum of 23 hours, 59 minutes and 59.99 seconds.

NOTE: You can leave the chronograph running while switching over to other operating modes. The chronograph indicator  will be displayed in DATE/TIME, BIG TIME and WORLD TIME display formats of NORMAL TIME mode when the chronograph is in use.

## TO SET THE TIMER:

1. Press S3 sensor to select TIMER mode.
2. Press and hold S2 sensor, the message "HOLD TO SET" will be displayed for approximately 2 seconds and the hour digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value.
3. Press S3 sensor, the minute digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value.
4. Press S3 sensor, the second digits will blink. Press S1 sensor to increase or S2 sensor to decrease the value.
5. Press S3 sensor, the action-at-end\* setting will blink. Press S1 or S2 sensor to toggle between STOP AT END and REP (REPEAT) AT END.
6. When finished making all the settings, press and hold S2 sensor for approximately 2 seconds to confirm.

NOTE\*: Illustration of the action-at-end setting:

- a) STOP AT END – the timer will stop when the countdown reaches zero.
- b) REP AT END – the timer will reload and repeat the countdown when the countdown reaches zero.



## TO USE THE TIMER:

1. Press S3 sensor to select TIMER mode.
2. Press S1 sensor to start counting.
3. To stop counting, press S1 sensor. Press S1 sensor again to resume from where it left off.
4. To reload the timer, press S1 sensor to stop counting and then press S2 sensor.
5. Upon completion of a countdown, the watch will react according to the action-at-end setting selected:

If STOP AT END is selected, the timer will stop when the countdown reaches zero. A timer alert tune will be emitted.

If REP AT END is selected, the timer will reload and repeat the countdown when the countdown reaches zero. If the timer is set to be 30 seconds or less, the timer will repeat with a “beep-beep” sound generated; if the timer is set to be more than 30 seconds, the timer will repeat with a timer alert tune generated.

NOTE: The touch sensor lock will not be activated in TIMER mode when the timer is in use.

NOTE: You can leave the timer running while switching over to other operating modes. The timer indicator  (STOP AT END)/  (REPEAT AT END) will be displayed in DATE/TIME, BIG TIME and WORLD TIME display formats of NORMAL TIME mode when the timer is in use.

## TO USE THE BACKLIGHT:

Press S4 sensor to turn on the backlight for approximately 3 seconds.

## DIGITAL WATCH WITH SCROLL BUTTON

S1 – Mode Button (by scrolling);  
Unlock/set/start/stop Button  
(by pressing)

S2 – Light Button



### TO LOCK AND UNLOCK THE SCROLL BUTTON:

Your watch is equipped with a scroll button (S1 button). To avoid triggering the scroll function accidentally, the scroll button is locked during normal wear. To unlock the scroll button, press S1 button once. The watch will beep once to indicate the scroll button is unlocked.

When no buttons are pressed or scrolled for 10 seconds, the scroll button lock will automatically be activated (except in CHRONOGRAPH mode and TIMER mode when the chronograph or timer is in use). The watch will beep once to indicate the scroll button is locked.

### DISPLAY MODES:

The watch has five display modes: TIME, CALENDAR, ALARM, CHRONOGRAPH and TIMER.

To change from one display mode to another, scroll S1 button. Scroll clockwise to the next mode or counter-clockwise to the previous mode.

**NOTE:** In any setting mode, when there is no button pressed for approximately 2 minutes, the watch will automatically save the entered data and exit to TIME mode.

## TO SET THE TIME:

1. Scroll S1 button to select TIME mode.
2. Press and hold S1 button for approximately 2 seconds, the hour digits will blink. Scroll S1 button to set the hour digits. Scroll clockwise to increase or counter-clockwise to decrease the value.
3. Press S1 button, the minute digits will blink. Scroll S1 button to set the minute digits. Scroll clockwise to increase or counter-clockwise to decrease the value.
4. Press S1 button, the second digits will blink. Scroll S1 button to reset the second digits to zero.
5. Press S1 button, the hour format setting will blink. Scroll S1 button to toggle between 12-hour and 24-hour format. The "P" indicator will be displayed to indicate the time period 12:00 P.M. – 11:59 P.M. in 12-hour format.
6. Press S1 button, the "BEEP" setting will blink. The "BEEP" option will cause the watch to beep anytime S1 button is scrolled or pressed. Scroll S1 button to toggle between ON and OFF for the beep setting.
7. When finished making all the settings, press and hold S1 button for approximately 2 seconds.

NOTE: The "BEEP" setting is not applicable to the beep emitted during the locking and unlocking of scroll button.

## TO SET THE CALENDAR:

1. Scroll S1 button to select CALENDAR mode.
2. Press and hold S1 button for approximately 2 seconds, the year digits will blink. Scroll S1 button to set the year digits. Scroll clockwise to increase or counter-clockwise to decrease the value.
3. Press S1 button, the month digits will blink. Scroll S1 button to set the month digits. Scroll clockwise to increase or counter-clockwise to decrease the value.



4. Press S1 button, the date digits will blink. Scroll S1 button to set the date digits. Scroll clockwise to increase or counter-clockwise to decrease the value.
5. Press S1 button, the date format setting will blink. Scroll S1 button to toggle between MM-DD (month-date) and DD-MM (date-month) format.
6. When finished making all the settings, press and hold S1 button for approximately 2 seconds.


NOTE: The date can be set within the range of 1 January 2010 to 31 December 2099.

### **TO SET THE ALARM TIME:**

1. Scroll S1 button to select ALARM mode.
2. Press and hold S1 button for approximately 2 seconds, the hour digits will blink. Scroll S1 button to set the hour digits. Scroll clockwise to increase or counter-clockwise to decrease the value.
3. Press S1 button, the minute digits will blink. Scroll S1 button to set the minute digits. Scroll clockwise to increase or counter-clockwise to decrease the value.
4. When finished making all the settings, press and hold S1 button for approximately 2 seconds.

NOTE: The alarm will automatically be activated after being set.

### **TO TURN ON/OFF THE ALARM:**

In ALARM mode, press S1 button to toggle between ON and OFF of the alarm. When the alarm is ON, the alarm indicator  will appear in TIME mode.

## **WHEN AN ALARM GOES OFF:**

A 20-second alarm tune will be emitted and the backlight will flash at the designated time when the alarm is activated. To stop the tune, press or scroll any button.

If the alarm tune is done without any user interruption, the alarm will go off again after 20 seconds for 2 times.

## **TO USE THE CHRONOGRAPH:**

1. Scroll S1 button to select CHRONOGRAPH mode.
2. The chronograph will then be displayed in its current state – stopped, running, or reset.
3. To resume a stopped counting, press S1 button to resume from where it left off.
4. To start a new counting, reset the chronograph to zero first. Press S1 button to stop counting, then press and hold S1 button for approximately 2 seconds to reset the counter to zero.

For the measurement of elapsed time:

In CHRONOGRAPH mode,

1. Press S1 button to start counting.
2. To stop counting, press S1 button. Press S1 button again to resume from where it left off.
3. To reset to zero, press S1 button to stop counting and then press and hold S1 button for approximately 2 seconds.

**NOTE:** You can leave the chronograph running while switching over to other operating modes.

**NOTE:** The chronograph can count up to a maximum of 23 hours, 59 minutes and 59.99 seconds.

## TO SET THE TIMER:

1. Scroll S1 button to select TIMER mode.  
Press and hold S1 button for approximately 2 seconds, the hour digits will blink. Scroll clockwise to increase or counter-clockwise to decrease the value.
2. Press S1 button, the minute digits will blink. Scroll clockwise to increase or counter-clockwise to decrease the value.
3. Press S1 button, the second digits will blink. Scroll clockwise to increase or counter-clockwise to decrease the value.
4. When finished making all the settings, press and hold S1 button for approximately 2 seconds to confirm.

## TO USE THE TIMER:

1. Scroll S1 button to select TIMER mode.
2. The timer will then be displayed in its current state – stopped, running, or reset.
3. To resume a stopped counting, press S1 button to resume from where it left off.
4. To start a new counting, reload the timer first.  
Press S1 button to stop counting, then press and hold S1 button for approximately 2 seconds to reload the timer.
5. When reaching zero in a countdown, a tune will be emitted. To stop the tune, press or scroll any button. The timer will reload automatically.

NOTE: You can leave the timer running while switching over to other operating modes.

## TO USE THE BACKLIGHT:


Press S2 button to turn on the backlight for approximately 5 seconds.

## ANALOG / DIGITAL THREE-HAND WITH DIGITAL WINDOW

S1 – Start/stop Button

S2 – Set Button

S3 – Mode Button



### TO SET THE ANALOG TIME:

1. Pull crown out to first click position B.
2. Turn crown to set time.
3. Push crown back to position A.

### DIGITAL DISPLAY MODES:

The watch has four display modes: NORMAL TIME, ALARM, CHRONOGRAPH and CALENDAR.

To change from one display mode to another, press S3 button once.

### TO SET THE DIGITAL TIME:

1. Press S3 button to select NORMAL TIME mode.
2. Press and hold S2 button for approximately 2 seconds, the second digits will blink.

3. Press S1 button to reset the second digits to zero.
4. Press S2 button once, the minute digits will blink.
5. Press S1 button to set the minute digits. Holding down the button will speed up the process.
6. Press S2 button once, the hour digits will blink.
7. Press S1 button to set the hour digits.
8. Press S2 button once, the hour format will blink.
9. Press S1 button to toggle between 12-hour and 24-hour format. The P.M. indicator may be displayed to indicate the time period 12:00 A.M. – 11:59 P.M. in 12-hour format.
10. When finished making all the settings, press S2 button to confirm.

### **TO SET THE CALENDAR:**



1. Press S3 button to select CALENDAR mode.
2. Press and hold S2 button for approximately 2 seconds, the date digits will blink.
3. Press S1 button to set the date digits.
4. Press S2 button once, the month digits will blink.
5. Press S1 button to set the month digits.
6. Press S2 button once, the day (of the week) digits will blink.
7. Press S1 button to set the day digits.
8. When finished making all the settings, press S2 button to confirm.

## TO SET THE ALARM TIME:

1. Press S3 button to select ALARM mode.
2. Press S2 button, the hour digits will blink.
3. Press S1 button to set the hour digits. Holding down the button will speed up the process.
4. Press S2 button once, the minute digits will blink.
5. Press S1 button to set the minute digits.
6. When finished making all the settings, press S2 button to confirm.

## TO TURN ON/OFF THE ALARM AND HOURLY CHIME:

In ALARM mode,

1. Press S1 button once to activate the daily alarm. Alarm indicator  will appear.
2. Press again to deactivate the daily alarm. Alarm indicator  will disappear.

## TO USE THE CHRONOGRAPH (STOPWATCH):

1. Press S3 button to select CHRONOGRAPH mode.
2. The chronograph will then be displayed in its current state – reset, running, or stopped.
3. To resume a counting, press S1 button to resume from where it left off.
4. To start a new counting, reset the chronograph to zero first.  
Press S1 button to stop counting, then press S2 button to reset counter to zero.

For the measurement of elapsed time,

1. Press S3 button to select CHRONOGRAPH mode.
2. Press S1 button to start counting.
3. To stop counting, press S1 button once. Press S1 button again to resume from where it left off.
4. To reset to zero, press S1 button to stop counting, then press S2 button to reset counter to zero.

For the measurement of split time,

1. Press S3 button to select CHRONOGRAPH mode.
2. Press S1 button to start counting.
3. While the chronograph is running, press S2 button once to register a lap. The lap time of the previous lap will be displayed yet the chronograph is still running in the background. Press S2 button again to display the currently accumulated lap time.
4. Repeat the last step until all the laps have been registered.
5. To reset to zero, press S1 button to stop counting, then press S2 button to reset counter to zero.

## WATCH WITH VIBRATION ALARM

- 1- Hour Hand
- 2- Minute Hand
- 3- Second Hand

- S1 – Mode Button
- S2 – Set Button
- S3 – Light Button



### TO SET THE ANALOG TIME:

1. Pull crown out to first click position B.
2. Turn crown to set time.
3. Push crown back to position A.

### DISPLAY MODES:

The watch has three display modes: TIME (TM), DATE (DT) and ALARM (AL).

To change from one display mode to another, press S1 button once. The mode description will appear for approximately 2 seconds before the selected mode is activated.

**NOTE:** In any setting mode, if there is no button pressed for approximately 60 seconds, the watch will automatically save the entered data and exit the setting procedure.

### TO SET THE DIGITAL TIME:

1. Press S1 button to select TIME mode.
2. Press and hold S2 button for approximately 2 seconds, the hour indicator will blink.



3. Press S1 button to set the hour indicator. Holding down the button will speed up the process.
4. Press S2 button, the minute digits will blink.
5. Press S1 button to set the minute digits. Holding down the button will speed up the process.
6. When finished making all the settings, press S2 button to confirm.

NOTE: The P.M. indicator will be displayed to indicate the time period 12:00P.M.-11:59P.M. in TIME mode.

### **TO SET THE DATE:**

1. Press S1 button to select DATE mode.
2. Press and hold S2 button for approximately 2 seconds, the month indicator will blink.
3. Press S1 button to set the month indicator. Holding down the button will speed up the process.
4. Press S2 button, the date digits will blink.
5. Press S1 button to set the date digits. Holding down the button will speed up the process.
6. When finished making all the settings, press S2 button to confirm.

### **TO SET THE ALARM TIME:**

1. Press S1 button to select ALARM mode.
2. Press and hold S2 button for approximately 2 seconds, the hour indicator will blink.
3. Press S1 button to set the hour indicator. Holding down the button will speed up the process.
4. Press S2 button, the minute digits will blink.
5. Press S1 button to set the minute digits. Holding down the button will speed up the process.

6. When finished making all the settings, press S2 button to confirm.

## **TO TURN ON/OFF THE ALARM AND VIBRATION ALARM:**

In ALARM mode,

1. Press S2 button to active the melody alarm. The melody alarm indicator ◀ will appear.
2. Press again to active the vibration alarm. The vibration indicator ▶ will appear.
3. Press the third time to activate both functions. Both indicators will appear.
4. Press the fourth time to deactivate both functions. Both indicators will disappear.

## **WHEN AN MELODY ALARM AND VIBRATION GOES OFF:**

A 20-second alarm melody will be emitted and/or the watch will vibrate at the designated time when the melody alarm and/or vibration alarm is/are activated. To stop the melody and/or vibration, press any button.

## **TO USE THE BACKLIGHT:**

Press S3 button to turn on the backlight for approximately 5 seconds.

**AUTOMATIC WATCHES:**


The Automatic Self-Winding Mechanical Watch is not operated by a battery. You must wind it six or seven times before wearing. After that, your daily activity should wind the watch sufficiently to keep it running at night when it is not being worn. Occasional supplementary manual winding may be necessary. It is suggested that your mechanical watch be cleaned and oiled periodically to insure optimum performance. As this is a mechanical watch, quartz watch accuracy cannot be expected.

**TO WIND THE MAINSPRING:**

1. Hand wind by turning the crown clockwise in position A. Wind 15-20 times.
2. The wearer can also wind the watch by moving his/her wrist from side to side several times.

## AUTOMATIC THREE-HAND MODELS

1. Hour Hand
2. Minute Hand
3. Second Hand



(TY2807)



(TY2807)



(TY6C1K)




(TY2836SK)

### TO SET THE TIME:

1. Pull the crown out to first click position B.
2. Turn crown to set time.
3. Push crown back to position A.

## AUTOMATIC MULTI-FUNCTION

- 1.Hour Hand
- 2.Minute Hand
- 3.Second Hand
- 4.Month Indicator
- 5.Day (of the week )  
Indicator
- 6.24 Hour Indicator
- 7.Date Indicator



- S1 Month Set Button  
S2 Date Set Button

### TO SET THE DAY (OF THE WEEK):

1. Pull crown out to first click position B.
2. Turn crown to set day.
3. Push crown back to position A.

**NOTE:** The Day Indicator will move together with the Hour Hand and Minute Hand. Keep turning the crown until the desired day has been reached.

### TO SET THE TIME:

1. Pull crown out to first click position B.
2. Turn crown to set time.
3. Push crown back to position A.

**NOTE:** The 24 Hour Indicator will also be set during time setting.

**TO SET THE DATE:**

Press S2 button to set the date.

**TO SET THE MONTH:**

Press S1 button to set the month.







For repair and warranty information,  
please visit our website at:

**[www.genevawatchgroup.com](http://www.genevawatchgroup.com)**

47-14 32nd Place  
LIC, NY 11101  
1-800-874-0907

KCWB0711